






**DNZ80X / DNZ90X / DNR10X  
DNR11X / DNR12X / DNR13X / DNR14X  
Instruction Manual**






1  ST4x40 x3	2 	3  x1	4  x1	5  x1	6  x1	7  x1	8  ST4x40 x1	9  x1	10  x1
11  x1	12  x1	13  x1	14  x1	15  x1	16  x1	17  ST4x30 x2	18  x1	19  x1	20  x1




1



Right





Left



2





5

